



Use one of the following tools:

**Move** wheel and **Select** button



Tactile switches  
(or your sip-and-puff)



Touch screen



**Note:** If you want to listen to instructions and ballot choices, use headphones or a neckloop.

# How to cast your ballot using Verity Touch with Access

**1** If multiple languages are available, select one.



**2** Enter your access code and select **Accept**.



**3** When you're ready, select **Begin Voting**.



**4** Select each choice; then select **Next** to move to the next contest.



**5** Review your ballot. When you're ready, select **Cast ballot**.



**6** Select **Yes, cast my ballot**. A waving American flag appears, indicating success.

